

## How to use the Directional Key



- To navigate down, swipe your finger or thumb along the OK Key from top to bottom, as shown above.
- Swipe and Hold your finger or thumb from the top of the OK Key and holding at the bottom of the OK Key to scroll down.

Scrolling will only work correctly if you swipe up, down, left or right through the center of the OK Key.

